



Bracket Mounting Instructions

For EcoLux Air Dispenser wall mounted holders

Adhesive Mounting

1. **Clean the Wall Thoroughly:** Use rubbing alcohol to wipe the wall surface where the bracket will be installed. *This step is critical for proper adhesion.*
2. **Bracket Placement:** If needed, use the enclosed template to help level and position the brackets for single, double, or triple bottle configurations.
3. **Apply Tape to Bracket (Handle with Care):** Peel off one side of the 3M tape and carefully apply to the back of the bracket, ensuring it fits within the edges. *Avoid touching the adhesive surface of the tape to maintain its bonding strength.*
4. **Apply Adhesive Gel:** Apply a clear, waterproof construction-grade adhesive (e.g., Loctite Power Grab Ultimate Crystal Clear) to all areas of the bracket back that are not covered by tape.
5. **Mount the Bracket:** Remove the remaining liner from the tape. *Avoid touching the adhesive surface of the tape to maintain its bonding strength.* Firmly press the bracket onto the cleaned wall surface. While holding the bracket in place, wipe away any excess adhesive that may squeeze out.
6. **Cure Time:** Allow a 24-hour waiting period prior to loading bottles to ensure that the adhesive has set.
7. **Prepare Dispenser Bottles:** Before mounting the bottles, twist the pump tops several times until they pop up, indicating they are ready for use.

Drill Mounting

1. **Bracket Placement:** If needed, use the enclosed template to help level and position the brackets for single, double, or triple bottle configurations.
2. **Mark and Drill Holes:** Using the holes in the bracket as a guide, mark the desired drill points. Drill into the wall and insert plastic anchors. *Note: If necessary, trim the anchor tips to ensure they sit flush with the wall surface.*
3. **Secure the Bracket:** Align the bracket with the installed anchors and screw it to the wall.
4. **Prepare the Dispenser Bottles:** Prior to mounting the bottles, twist the pump tops several times until they pop up, indicating they are ready for use.

Additional Notes

- Although holders are suitable for most surfaces, they are not guaranteed for all. Please ensure that the dispenser is suitable for the desired surface prior to installation.
- Ensure that all brackets are installed at a uniform height.
- Avoid installing brackets in locations obstructed by showerheads or other fixtures.
- Place the dispenser near the corner to reduce hazard.
- The Bracket Mounting Template is designed to space finished, installed bottles approximately $\frac{3}{4}$ " apart.
- For best results, clean both the wall and bottles using mild soapy water and a microfiber cloth. In areas with hard water, vinegar may be used to remove limescale. *Avoid using harsh chemicals or abrasive cleaners.*
- To load bottle, slide it downward into the bracket and press until it clicks into the locked position. To remove bottle, use the included white key tool to unlock it from the bottom of the bracket.