


CLEANMAX
ZM-200

PARTS BOOK


HANDLE

ZM-200



HANDLE**ZM-200**

Key	Parts No.	Description
1	B431-2300	Handle Grip
2	B431-2406B	Handle Tube
3	D431-2406	Handle Tube Assembly with Grip
4	D431-3014	Lower Handle Upper Fan Housing
5	B431-2914E	Handle Tube Bracket
6	A432-0705	Screw, #10-32x1.625
7	A732-8314	Screw, #8x5/8"
8	A434-1241	Power Cord
9	B430-1205	Metal Cord Hook
10	A432-0805	Hex Nut
11	B211-2214	Bag Collar Bag Holder
12	B211-2114	Bag Collar Bag Ring
13	B211-3700	Cloth Bag
14	B211-1204	Lowr Bag Spring
15	B211-1914E	Lower Bag Clip
	A732-3600	Bag Clip Plug (Not Shown)
16	CMZM-H6	HEPA Bag (6 pack)
	CMZM-P6	Paper Bag (6 pack)
17	D211-5700	Bag Collar Seal
18	A732-9206	Screw



NOZZLE**ZM-200**

Key	Parts No.	Description
1	B017-3714	Nozzle Housing
2	B028-0014	Foot On/Off Pedal
3	A432-0805	Hex Nut
4	D431-3014	Lower Handle Upper Fan Housing Assembly
5	B123-3814	Fan Duct Cover
6	A121-0200E	Fan Duct Cover Felt Ring Seal
7	B123-3614	Lower Fan Housing
8	B123-3000	Fan
9	A121-0100E	Motor Bracket Felt Ring Seal
10	D113-1200	Motor/Fan Assembly
11	B029-0314	Furniture Guard
12	A732-8314	Screws
13	CMZM-BB	Belt (Bulk)
	CMZM-B2	Belt (2 pack)
14	B010-0101	Large Wheel Axle
15	B350-6531	Wheel Rear
16	D016-1114	Base Tray Assembly
17	B010-0001	Base Plate Wheel Axle
18	B010-2131	Base Plate Wheel
19	B012-2800C	Wood Agitator w/End Caps
20	B012-2914	End Cap
21	B015-2014	Base Plate Cover
22	A732-2500	Combination Screw (m4x12)
23	A028-0014	On/Off Foot Switch
24	B016-1230	Upright Stop
25	A028-0114	Circuit Breaker
26	B034-0100	Strain Relief Washer
	A732-3000	E-Clip for Motor Shaft (Not Shown)